

VIP Remote

User Manual



DroidBOXTM .CO.UK
DroidBOX .CO.UK

Thank you for purchasing this product, the guidelines below contain important information about the safe and proper use of this device. To avoid damage to you or the device, please read these instructions carefully before use:

1. Store the unit away from high temperature, extreme moisture or dust.
2. Avoid any strong blows to the product.
3. This product is a high precision electronic product, do not disassemble it or clean with alcohol, thinners or benzene solution.
4. The manufacturer reserves the right to upgrade the product, product specification and design is subject to change without prior notice.
5. Disclaimer: The manufacturer assumes no responsibility for data loss.
6. The unit is not water-proof.
7. Pictures contained in this manual are for reference only.

The VIP remote control

To use the VIP remote control, insert a couple of AAA batteries after removing the USB dongle from the battery compartment. To remove the battery cover, place your thumbs just above the Backspace and Enter keys, press down, and slide the cover off.















If you have already plugged the dongle in, before reading this section, remove it from the X7 Ultimate. Now press the TV button (almost bottom left) and the blue OK button at the same time, until the flashing LED changes from fast to slow. Now quickly plug the dongle into the X7 Ultimate, and the two items should be paired. If this does not work, try a different USB socket on the device.

To turn on your DroidBOX device, press the Standby button. If it does not work, press the TV button once and try again.

If you want to turn off the Air Mouse function (where moving the remote control around in front of you will move the onscreen cursor), press the button with a cursor and power icon on it. To re-enable it, press the button once again. On a related note, when you flip the remote control over to access the QWERTY keyboard, the Air Mouse function is automatically turned off until you turn the remote back over again.

If you want to change the sensitivity of the Air Mouse, please bring up the list of installed Android apps, and select Settings→Language and Input and click on it. Scroll the right hand section of the screen until you see Pointer Speed. Click on it, and select your desired speed and click OK.

The remote control can be taught to mimic infrared remote control functions. If you find that you don't use one key at all, then you could train the VIP remote to use it as a Standby button for your television, for example. To teach the VIP remote a command, line up the top of the two remotes on a stable surface. Hold down the "TV" button on the VIP remote for a couple of seconds, until the rapidly flashing LED slows down a little. Now press (once) the button on the other remote that you want to teach the VIP remote to mimic. Next press the button the VIP remote that you want to assign the taught function to. As some VIP remote buttons are not used in every Android application, you could also remap them to independently adjust the volume of your TV, or switching the Video Source selection.

Key	Function
	Power on/off/standby. Switch device compatibility mode with red TV button first
	Rewind
	Fast Forward
	Previous Track - Switch to previous program while playing
	Next Track - Switch to next program while playing
	Search key shortcut
	Play/Pause
	Zoom in
	Zoom out
	Menu key shortcut
	Home key shortcut
	Back/Return key shortcut
	Up, down, left & right cursor keys
	Functions as a screen tap

	Mute the sound
	Turn Air Mouse function off/on. Turn off if putting your device into standby/suspend mode
	Increase volume
	Decrease volume
	Page/Channel Up
	Page/Channel Down
	Numbers
	Backspace - delete a character, left of the cursor
	Press to switch Standby button between X7,Q7/iMX8 and iMX6/M8 compatible modes Also used to configure VIP remote
	Various configurable shortcut buttons
	QWERTY keyboard underneath the remote
	Caps Lock key
	Press once to use the alternative symbols on the keyboard, press again to return to QWERTY

© 2014 DroidBOX Ltd